

Installation

The improper mounting of the detector and improper arrangement of the rolls will result in unsatisfactory control performance, or will cause wrinkles to the web. When planning and aligning the process line, the following described items must keep in mind.

A. Unwinding (pay off reel system)

B. If the material wound is irregular, this system guide the edge position and let it regularly into the subsequent process.

The idler roll moves with the unwinding reel stand.

Mount the detector fixed and as close to the idler roll as possible.

The leaving web formed a angle at the deflector roll should more than 30°

The important, do not allow the web slip on this roll.

The distance between two rolls should be more than the maximum width of the web.



